

Setback Distances in feet
 Lac Qui Parle County, Minnesota Table date: March 7, 2012

Map Unit Symbol	Drain Depth, feet			
	2	3	4	5
34	50	80	100	120
47	50	80	100	120
51	60	80	100	120
60	80	120	150	190
67	50	60	70	90
70	60	90	110	130
85	60	90	110	130
108	50	70	90	110
113	50	50	70	80
137	50	70	80	100
184	50	70	90	110
210	50	60	80	100
219	50	60	80	90
236	50	50	70	80
246	160	280	370	400
276	50	60	80	90
314	160	290	400	400
338	50	70	90	110
339	140	250	340	400
344	60	80	100	120
347	130	240	330	400
375	170	290	390	400
418	70	110	150	180
423	50	70	80	100
434	50	80	90	110
450	90	120	150	180
497	70	100	130	150
509	50	50	60	70
574	50	80	110	120
597	50	70	90	110
610	60	90	110	130
680	50	70	90	100
706	50	70	90	110
724	50	70	90	110
774	60	90	110	130

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.

Setback Distances in feet
 Lac Qui Parle County, Minnesota Table date: March 7, 2012

	883	100	200	280	360
	1051	50	60	80	100
	1108	50	60	70	80
	1222	50	110	160	210
	1296	60	80	100	120
	1870	60	90	110	140
	1938	50	60	70	80
	1994	90	160	210	270
	1233B	60	90	120	150
	127A	130	210	280	340
	127B	130	210	280	340
	1295B	50	60	80	90
	141A	110	170	230	300
	141B	110	170	230	300
	168B	50	70	90	110
	1865C	50	60	70	90
	212A	50	70	90	100
	212B	50	60	70	90
	284B	50	70	80	100
	290B	110	170	220	270
	293B	80	100	120	140
	341A	180	290	380	400
	341B	180	290	380	400
	421B	50	70	90	100
	494B	50	70	90	100
	741B	60	90	120	140
	748B	60	80	110	130
	769A	50	70	90	110
	769B	50	70	90	110
	891B	50	60	80	90
	902B	50	60	70	90
	954B	50	70	90	100
	969B	90	150	190	240
	L201A	50	70	90	110
	L84A	50	60	70	90

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.