Setback Distances in feet
Watonwan County, Minnesota Table date: March 8, 2012

Map Unit Symbol	Drain Depth, feet			
	2	3	4	5
35	80	120	140	160
84	50	60	80	90
86	50	60	80	90
112	50	50	60	70
113	50	60	70	90
114	50	60	70	90
118	50	70	80	100
130	50	70	90	100
134	50	60	80	90
136	60	90	110	130
140	60	90	110	140
160	90	140	180	220
178	80	160	210	270
181	90	160	230	290
183	120	220	300	380
197	60	90	120	140
227	130	220	290	370
229	50	70	90	110
247	130	220	290	310
255	120	200	300	360
269	50	50	60	70
281	80	120	180	250
282	150	260	350	400
336	50	50	70	80
362	50	70	90	110
392	120	240	340	400
423	50	70	80	100
487	100	170	240	300
517	50	100	140	180
539	50	90	110	130
562	50	70	80	100
575	50	60	70	90
654	50	70	80	100
668	80	130	170	210
929	90	150	200	250

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.

Setback Distances in feet
Watonwan County, Minnesota Table date: March 8, 2012

956	50	60	70	90
1016	50	50	60	70
1055	50	60	70	90
1833	50	50	60	70
1834	50	50	50	70
1907	60	90	110	140
1981	60	100	130	160
1981	60	100	130	160
101B	60	90	110	130
102B	50	70	90	110
128A	80	110	140	170
128B	70	100	130	160
222B	100	160	210	250
27A	80	160	210	270
27B	80	160	210	270
327A	140	220	290	360
327B	140	220	290	360
41B	140	230	300	380
421B	50	70	90	100
639B	90	160	220	280
789B2	90	150	210	260
790B	70	110	140	170
887B	50	70	90	110
8B	130	210	270	330
909C2	80	120	150	180
920B2	50	70	90	110
921B2	50	70	90	110
954B2	50	70	80	100
999B2	50	70	80	100
L107A	50	70	90	100
L13A	60	90	120	140
L163A	50	60	80	100
L201A	50	70	90	110
L83A	50	60	80	90
L84A	50	60	70	90
L85A	50	60	80	100

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.